TEXIO

取扱説明書

ラック・マウント・アダプタ

OM-15E

株式会社 ニッケテクノシステム
© PRINTED IN JAPAN B68-0017-00

1. 付属されている部品

記号	品名		数量
C	ラックマウント金具		2 個
D	取付ネジ(サラネジ)	M4×16mm	4 本
E	山形ワッシャ		4 個
F	丸皿ネジ	M5×14mm	4 本
G	フレーム		2 個
H	皿ネジ	M3×8mm	4 本

2. 取付け前の準備

左右のサイドカバー**A** (前側のみ 2 個)を取付けているネジ **B** 2 本(計 4 本)をゆるめてはずします。(図 1 参照)

3. ラックマウント金具の取付け

① ラックマウント金具 **C** (左右共通)の取付け穴(長穴ではない)に、準備の時にはずしたサイドカバーのネジ穴 2 箇所を合わせ、取付けネジ(M4×16mm) **D** を使用して、セットに取付けます。(図 2 参照)

② フレームをセットの上下に皿ネジ(M3×8mm) **H** を使用してラックマウント金具に取付けます。

③ ラックマウント金具を装着したセットをラック本体に取付けるときは、付属の山形ワッシャ **E**、丸皿ネジ **F** を使って、ラック本体にネジ止めします。(図 2 参照)

注意: ラック本体に取付けたあとは必ず、セット本体を下側からアングルサポート金具等で支えてください。



図1



図2



取付図

TEXIO

INSTRUCTION MANUAL

RACK MOUNT ADAPTER

OM-15E

NIKKE TECHNO SYSTEM CO.,LTD.
© PRINTED IN JAPAN B68-0017-00

1. CONTENTS

Symbol	Name		Q'ty
C	Rack mount adapter		2
D	Set screw (Countersunk head screw)	M4 × 16mm	4
E	Angle washer		4
F	Oval countersunk head screw	M5 × 14mm	4
G	Frame		2
H	Countersunk head screw	M3 × 8mm	4

2. PREPARATION

Remove each two screws **B** , which fix the side covers **A** in the front of the right and left side panels (four screws in all). (See Fig.1 below)

3. ATTACHING RACK MOUNT ADAPTERS

① Fit the holes (not the slotted holes) in the rack mount adapter **C** to two threaded holes, from which the screws have been removed in PREPARATION above. (The right and left rack mount adapters are quite the same.) Attach the rack mount adapter to the equipment with two set screws **D** (M4 × 16mm). (See Fig. 2 below)

② Fit the frames to the rack mount adapter on the top and bottom of the equipment with the countersunk head screws **H** (M3 × 8mm).

③ Mount the equipment with the rack mount adapters to the rack with the angle washers **E** and oval countersunk head screws **F** . (See Fig.2 below)

NOTE: Be sure to support the equipment with angle support brackets, etc. from beneath after mounting the equipment to the rack.



Fig.1



Fig.2